

Reed Type PVC Valve

Installation Instructions

Drill a 1.5mm safety hole inside (Figure 1). To be sure that no oil-mix blocks the valve, mount the valve so the inlet is on the top and the outlet is on the bottom (Figure 2). You can also mount the reed valve vertically as shown (Figure 3).

FIGURE 1



FIGURE 2



FIGURE 3

