


# # 24-6522

## **ALL ELECTRIC START 650'S** **ERRATIC STARTER ENGAGEMENT**

Erratic Electric Starter Engagement and Disengagement on Yamaha 650 Twins is often the result of the improper functioning of the three parts described below. Replacement of these parts with the indicated improved parts (only as set), will generally cure erratic engagement problems.



### **PARTS LIST:**

REF. NO.	DESCRIPTION	QTY
2	Spring	1
3	Clip	1
4	Gear	1

Note: These parts are standard XS650 parts. They may be used as a set on all 650 Yamaha Twins with electric starters. Parts contained in kit #24-6522 replace all earlier versions of these parts.

The clip (wishbone shaped spring) position is changed as shown below

